

CENTRALISED LABEL MANAGEMENT

User Manual for Wi-Fi Configuration

The Wi-Fi on the Label Management WSDL can be configured in 3 ways. This can be accessed via the Wi-Fi menu present on the keypad. The configuration methods are described below.





Via Hotspot

To begin with, install the IoTReady Wi-Fi Configuration application on mobile phone. Once done, follow these steps

1. Click on the 'Wi-Fi' menu and select the 'Hotspot' option on the WSDL using the keypad.
2. Create a hotspot using the IoTReady application.
3. You will be directed to a link once the hotspot is created.
4. Enter Wi-Fi SSID and password in their respective text fields
5. You will be connected to the Wi-Fi.



Scan to download the IoTReady Wi-Fi Configuration application




Via USB

This method requires a USB pen drive.

1. Create a .txt file named '**wifi.txt**' containing the Wi-Fi credentials in the given format.
2. Transfer the file to an empty USB drive.
3. Insert the USB drive to the WSDL device.
4. Click on the 'Wi-Fi' menu and select the 'USB' option.
5. You will be connected to the Wi-Fi.

```
wifi.txt
IoTReady    —————> Wi-Fi SSID
getiotready —————> password
```


Format of the .txt file



Via Type

This method requires the usage of a USB type keyboard.

1. Connect a USB keyboard to one of the USB ports at the bottom of the device.
2. Click on the 'Wi-Fi' menu and select the 'Type' option.
3. Enter Wi-Fi SSID and password in their respective text fields. Press 'Esc' button to enter.
4. You will be connected to the Wi-Fi.



PH1, Rich Homes, 5/1 Richmond Road, Bangalore - 560025